Product description

Double emptying system for liquid and pasty media 2 x 180 ccm Semco cartridges.

With a folding mechanism for replacing the cartridges. Via the material switch, reset buttons and controls, the container cartridges are alternately released and pressed out. This enables a seamless material supply of dosing valves, e.g. dispensers etc.

The currently active container is indicated by light.

Connection options for dosing valves via the material tube.

The container emptying works independently via an internal controller and also give signals to the outside.

The setting on the pressure manometers changes the pressure on the cartridges and thus the flow rate.

Technical description

- Pneumatic cylinder with throttle valves
- Pneumatic hand lever valves
- Material switch for alternate pressing
- Pressure regulator with manometer 0 6 bar
- Folding units for replacing cartridges
- Size approx.: 1208 x 500 x 191 mm (L / W / D)
- For media with low to medium viscosity, a PU tube 4 to 6 mm via G ½ connection is advised
- For highly viscous media, ask for the right tube size at axiss GmbH



